SPECIFICATIONS	KIT 1	KIT 2	KIT 3	KIT 4	KIT 5
Fuse Size	60 Amp Fuse	110 Amp Fuse	200 Amp Fuse	300 Amp Fuse	400 Amp Fuse
Cable Gauge	IC #6 – 10 ft.	IC #4 – 10 ft.	IC #2 – 10 ft.	IC #2/0 – 10 ft.	IC #4/0 – 10 ft.
Inverter	12V 100-400 watt 24V 100-600 watt	12V 600-1000 watt 24V 600-1800 watt	12V 1100-1800 watt 24V 2000-3000 watt	12V 2000-3000 watt 24V 3100-4000 watt	12V 2600-3000 watt 24V 4100-6000 watt
Go Power! Quick Check	GP-ISW200-12 (-24) GP-ISW400-12 (-24)	GP-ISW1500-24, GP-ISW- 2000-24, GP-ISW-	GP-1750HD, GP-ISW1500 GP-ISW2000, GP-2500HD	GP-ISW2000, GP-ISW3000	GP-ISW2000, GP-ISW3000
Included Items	Inline Fuse 60 10ft. 6 Awg Cables, 11" Cable Ties 5/16" Cable Clamps, #10x3/4" Screws	Inline Fuse 110 10ft. 4 Awg Cables, 11" Cable Ties 3/8" Cable Clamps, #10x3/4" Screws	Inline Fuse 200 10ft. 2 Awg Cables, 11" Cable Ties #10x3/4" Screws	Inline Fuse 300 10ft. 2/0 Aawg Cables, 11" Cable Ties 5/8" Cable Clamps, #10x3/4" Screws	Inline Fuse 400 10ft. 4/0 Awg Cables, 11" Cable Ties 3/4" Cable Clamps, #10x3/4" Screws



GP-DC-KIT DC INSTALL KIT MANUAL



© 2021 Go Power!

Worldwide Technical Support and Product Information gpelectric.com Go Power! | Dometic 201-710 Redbrick Street Victoria, BC, V8T 5J3

Tel: 1.866.247.6527

53498_MAN_GP-DC_Install_Kit



Be sure all charging sources (PV array, battery charger, etc.) and all loads (inverter, DC loads, etc.) are turned off before cutting or terminating cables.

WARNINGS

4	Avoid all electrical hazards	Disconnect batteries and electrical system from any power source of electrical power, before attempting to install your Go Power! Fuse Block
Â	Observe proper polarity	Observe proper polarity throughout the fuse block installation
A	Work safely	Do not wear jewelry when working with electrical or mechanical equipment. Use protective eyewear, gloves and apron when working with batteries or power tools. Use extreme caution when on ladders or a roof
	Follow the Safety Precautions	Follow the Safety Precautions of the battery manufacturer. Do not produce sparks when working in locations where flammable gases or vapours exist. Shield skin and eyes from battery acid. If skin, eyes or clothing comes in contact with acid rinse thoroughly with water.

^{*}Avoid electrical shock. Make sure all sources (inverter, shore power, generator) are disconnected

2. INSTALLATION OVERVIEW

Congratulations on becoming the owner of a GP–DC Kit. Please read and understand all instructions before installing your new product for the easiest and safest installation. Before installing kit, review the installation design with this DC kit Installation Manual. Contact your Authorized Go Power! Dealer if in doubt as to this kit's suitability or compatibility with your system. Retain this guide for future reference.

2.1 INSTALLATION

- 1. The inverter fuse is to be mounted on the positive cable near the battery.
- 2. **Kits 2 5 only**: Cut the positive (red) cable according to desired location. Strip $\frac{1}{2}$ " to $\frac{3}{4}$ " of insulation from the cables, and connect the fuse block as shown
- 3. **Kits 2 5 only**: Tighten the lugs to 10 ft. lbs.
- 4. Observe the polarity of the cables (red = positive) (black = negative) and connect accordingly to the inverter.

3. INSTALLATION DIAGRAM (KITS 2-5)



4. WARRANTY

The conditions or methods of installation, operation, use and maintenance of this kit and its solar module are beyond the control of Go Power! does not assume responsibility and expressly disclaims liability for loss, damage, or expense arising from, or in any way connected with such installation, operation, use, or maintenance.

Go Power! Inc does not cover labour or shipping for items returned.